

Riviera Srl Genova
Via Inferiore Rio Maggiore, 4A
16138 Genova (Italy)
Tel. +39 010 8355286 – info@rivieragenova.it

Azienda certificata ISO 9001 -







# USER'S MANUAL - Magnetic compass for navigation RIVIERA type PRISMA 2" 1/4

Dear Customer,

in thanking you for your preference and trust in our products, we wish to inform you that this marine magnetic compass has been designed and built to perfection in the RIVIERA srl factory in Genoa. After manual assembly, it was subjected to tests and quality controls in accordance with the requirements of the Italian shipping register, RINA. It is made with materials that have proven to guarantee its functioning aboard boats for many years.

Keep this manual together with the on-board documents.

### Installation

PRISMA hand bearing compass is simple, fast and accurate. Plot your position by sights or bearings on distant landmarks. On-off switch on the handle controls the self-contained battery that is particularly useful on faint lighting conditions, Prisma compass may be used as a steering compass being hold in a vertical position by a handy bulkhead clip.

#### **Maintenance**

Clean the Riviera compass with a soft cloth moistened with fresh water. Don't wash with solvents. In case an air bubble should appear in, turn the compass up, gently, pat it with the fingers. (Fig.1). When storing for long periods put it away in the optional wooden box taking care of removing the dry

When storing for long periods put it away in the optional wooden box taking care of removing the dry battery. To replace the lamp or the battery unscrew the screw on the bottom of the handle (Fig.2). Then pull the string to have the lamp holder and battery out (Fig.3).

Replace the concerned item and repeat the above mentioned operations in the inverse sequence.

Fig.1



Fig.2



Fig.3



**General features** 

Apparent diameter 2 ¼ (57,5 mm)

Mounting: quick bayonet joint

(bracket is incl.)
Dial gradation 5 °
Dial colors: white
Prismatic lens
Lighting 1,5 V CC

Gimbal type: Jewel and pivot

movements

Compensation not foreseen

3 years warranty

#### Liquid

The liquid contained in the RIVIERA compasses is stable in the temperature range from -30 ° to +60 ° C. In this range there should be no bubbles, this is guaranteed by an elastic membrane that compensates for volumetric variations. The liquid is Shell SoID / 70 (petroleum).

## **Packaging**

The RIVIERA ARIES compass is delivered in protective packaging suitable for international shipping

#### Repair

For the purposes of forfeiture of the warranty terms and for your safety, any repairs may be carried out only and exclusively by the manufacturer. In case of need, please contact RIVIERA SrI -info@rivieragenova.com

# Certificate of Warranty



This document is valid as a guarantee certificate.

The company RIVIERA srl Genoa guarantees that its compasses are built in a workmanlike manner and that they are free from manufacturing and material defects.

If within 36 months from the date of manufacture (stamped on the flange) the product should show malfunctions, the company will repair or replace it, at its sole discretion, free of charge.

The warranty is void if the damage is caused by improper use, incorrect installation or accidental breakage.

The warranty does not cover any costs deriving from assembly or disassembly of the products, transport of the same and expenses for technical personnel, even if attributable to manufacturing defects.

In the event of a dispute, the competent court is the court of Genoa.

